

5350 Getta carta con coperchio /
Paper basket with lid

Ø 210 x H 320 mm





Portabiancheria con coperchio /
Laundry basket with lid

5351 Ø 310 x H 540 mm


5352 Ø 365 x H 560 mm

5353 Ø 410 x H 570 mm





53309 Portabiancheria con coperchio e sacco in cotone /
Laundry basket with cotton bag, with lid
L 405 x H 670 x P 405 mm




53310 Portabiancheria con coperchio e sacco in cotone /
Laundry basket with cotton bag, with lid
L 405 x H 670 x P 405 mm




53311 Portabiancheria con coperchio e sacco in cotone /
Laundry basket with cotton bag, with lid
Ø 430 x H 650 mm



53312 Portabiancheria con coperchio e sacco in cotone /
Laundry basket with cotton bag, with lid
Ø 430 x H 650 mm



53431 Getta carta con coperchio /
Paper basket with lid
L 225 x H 330 x P 225 mm




Portabiancheria /
Laundry basket
53432 L 305 x H 640 x P 305 mm
53433 L 405 x H 650 x P 305 mm






53441 Porta salviette /
Tissue container

L 280 x H 90 x P 160 mm




53442 Gettacarta /
Paper basket

L 220 x H 325 x P 260 mm




53443 Portabiancheria /
Laundry basket

L 300 x H 600 x P 350 mm



7001 Portariviste /
Newspaper container
L 375 x H 355 x P 165 mm



7003 Cestino /
Paper basket
Ø 225 x H 250 mm



7005 Porta salviette /
Tissue container
L 260 x H 90 x P 130 mm



7006 Portabiancheria /
Laundry basket
Ø 310 x H 555 mm

